

CLICK WATER PROOF LAMINATE FLOORING INSTALLATION GUIDELINES

Before you start read these Installer/Owner Responsibilities:

Relative Humidity (RH) requirements: Laminate floors require a Relative Humidity of 35% - 50% continuously throughout the entire year. Installation over in floor radiant heat requires a Relative Humidity of 40% - 50% continuously throughout the entire year.

It is the installer/owner's responsibility to maintain the required RH within the recommended range throughout the year. Failure to maintain the required RH may damage the floor and void product warranty.

Before starting installation, it is important you read all instructions and warranty information. By starting installation of this product you are agreeing that you have read and understand all installer/owner's requirements and responsibilities and are aware that deviating from the instructions and recommendations in this installation guide may result in voiding the product warranty.

Verify colour and finish/gloss before installation. Once the floor is installed, it is deemed to have been inspected, approved and accepted.

It is the sole responsibility of the installer/owner, prior to installation, to assure that the planned installation area is suitable for laminate flooring and meets local building codes. Confirm that all subflooring is dry, sound, flat and meets or exceeds all industry standards/local building codes; as well as the recommendations listed herein. Do not install in a bathroom or kitchen (or any area prone to moisture).

The manufacturer accepts no responsibility for product failure extending from or related to failure to meet job area/environment and subflooring requirements. If the installation is for a newly built home or construction, the installer/owner must ensure all windows and doors are installed and that wall and floor boards are completely dry and that the homes HRV/heating/air-conditioning system is functional and running at living conditions to which the floor will be maintained. It is recommended that flooring be the last stage in a construction project.

The installer/owner assumes full responsibility for the final inspection of this product. Inspection should be done prior to installation and should include: print/colour/texture, factory finish/gloss and milling. If the product is not acceptable, **DO NOT INSTALL IT**. Contact your supplier immediately for assistance. Flooring that has been installed will be deemed to have been inspected and quality accepted.

If you wish to install over a radiant heating system consult with the manufacturer of your radiant heating system to ensure that it is compatible with laminate flooring. Temperature must never exceed 26° C (79° F) and changes in temperature settings must be gradual. Rapid temperature changes and/or excessive heat will damage the flooring and/or the finish. Humidity must be maintained between 40% and 55% continuously throughout the entire year. It is the responsibility of installer/owner to confirm the suitability of the radiant heating system for use with this product. Any damage to the floor caused by the radiant heating system will not be covered by the product warranty.

Suggested Tools for Installation:

Safety Glasses, Saw, Chalk Line, Tape Measure, 6' Straight Edge (or level), Shims, Pry-bar, Hammer.

Pre-installation:

When calculating flooring square footage requirements, allow a minimum of an additional 10% for cuts, waste and defects. If installing a diagonal or other special pattern, allow for 10% additional materials.

Acclimatize laminate flooring for a minimum of 48 hours. We recommend you leave the products in their original packaging until time of installation at a temperature of 68°F to 79°F (20°C to 26°C) at 35% to 50% relative humidity in the area in which the flooring will be installed. Protect flooring from excessive heat/cold or sources of high humidity during storage.

Subfloor Requirements:

All sub-floors must be clean, flat and dry prior to installation, regardless of installation method. Floors installed over non-flat subfloors may squeak and/or deflect when walked on. Sweep or vacuum your subfloor immediately prior to installation ensuring there is no debris or grit, as it may interfere with installation.

Wooden subfloors: Recommended $\frac{3}{4}$ " CDX plywood, OSB or boards (follow NWFA guidelines), must be flat, high or low areas exceeding $\frac{3}{16}$ " per 10' (5mm per 3m) or $\frac{1}{8}$ " per 6' (3mm per 2m) must be corrected. Sand down high areas, fill low areas. Nail or screw down any loose areas and replace any damaged sheathing (damaged, swollen or delaminating).

Concrete: most concrete subfloors (slabs) are not flat and must be leveled before installation. In all cases, verify the subfloor using a 10' long straightedge to locate high and low areas, low areas should be filled with a self-leveling compound. The moisture content of the concrete subfloor should not exceed 5%.

Underlayment:

Floating installations **require** an underlayment. Use an approved underlayment as recommended by your local dealer suitable for your chosen installation method.

Concrete slab / basement applications: If installing over concrete slabs, you must use a high performance vapour barrier (6 mil poly or equivalent) to protect your floor from slab-borne moisture. Failure to use an appropriate vapour barrier over concrete slabs in these cases may void the warranty. In addition to moisture protection, your choice of vapour barrier should also offer you acoustic performance.

Condos, two-story homes or buildings: In all cases, the use of an approved acoustic membrane is recommended to minimize the transfer of sound from level-to-level and improve the comfort level of the floor. Many municipalities have building codes for acoustic membranes; consult your local building codes or condo association for IIC and STC acoustic rating requirements.

Installation:

- In all cases, Click Laminate flooring should be installed perpendicular to the floor joists, unless you have added an extra sub-floor layer to stiffen the sub-floor to reduce sagging. Calculate the width of the install area and adjust the start/finish row boards to be at least $\frac{1}{2}$ a board wide.
- Stagger your end-joints by a minimum of 16" and avoid "H" patterns and "stair-steps".

CLICK FLOATING GENERAL INSTALLATION INFORMATION:

- For a click floating installation, follow the directives noted above regarding sub-floor preparation.
- Floating installations may be made over most subfloors including: Plywood or OSB, ceramic/porcelain tile, smooth stone, marble, granite, and linoleum. Do **NOT** install over carpet.
- For installation over concrete, you must first install a moisture barrier underlayment.
- For installation over an existing hardwood or engineered floor, you must ensure the old floor is properly secured down. Install the new floor perpendicular to the old floor. If you choose to install the new floor in the same direction, you must install a minimum 3/8" (10mm) approved underlayment sheathing over the top of the old floor for stabilization. Also, if the old floors are wider than 6" (150mm), it must be covered with a minimum 3/8" (10mm) approved underlayment sheathing for stabilization.
- Set up starting line for the first row by measuring the width of the plank. Add 3/8" (10mm) to 1/2" (12mm) to this number and mark the floor at each end of your starting wall, approximately 6" (150mm) away from the corners.
- Installation in rooms over 20' (6m) wide and /or over 40' (12m) long: If you are doing a installing floating and the width of the room exceeds 20' (6m) (across width of boards) and or 40' (12m) long (across length of boards), you need to install a T-moulding mid-room to allow the floor to naturally expand or contract with seasonal changes in humidity.
- Using a chalk-line, carefully snap a line between these two points. Check to make sure there will be approximately 3/8" (10mm) to 1/2" (12mm) between the edge of your first row of planks and the wall. This space allows for slight expansion of the laminate flooring and will be covered by the baseboard / quarter-round.
- Layout first row of boards, the short tongue should be facing the wall. First board should start a minimum of 3/8" (10mm) from the wall. Cut the last board to finish a minimum of 3/8" (10mm) from opposite wall. We recommend you use temporary shims to keep the floor away from the walls, as the floor will shift during installation due to it being a floating floor. Place the shims every 2-3' (60-90 cm) along the starting wall, plus at the end of each of the starting rows so boards do not shift when set into place.
- Assemble the end joints of the first row by lining up the lower end joint profile and upper end joint profile together and press-fit in place to lock the end joints (*you can tap lightly with a rubber mallet to assure it has locked in place*). Continue in this manner until the first row is complete.
- To start the second row, use the remainder of the last plank of the first row if it is longer than 30cm (12") long, otherwise, cut a new plank in half and proceed. To ensure structural integrity of your floor, it is mandatory to **ALWAYS STAGGER THE END JOINTS FROM ROW TO ROW BY AT LEAST 40cm (16")**. You must always leave the lower-lip of the drop-lock profile exposed for the next plank to be dropped into place. You cannot reverse the installation and must continue to start from the same side.
- Install one board at a time, always leaving the exposed lower profile and the lower press-fit profile exposed on the end joint. Lining your plank up to the previously installed plank in the same row, insert the small tongue of the plank into the larger lower lip groove profile at approximately a 22° angle on the long side profile. Push slightly forward and down, the plank

should drop into place with little resistance. Do not force the plank down, as this may damage the profile. If the plank will not drop, check the locking profile for debris or damage and re-try. Once the side profile is properly seated, press or lightly tap the end joints to lock in place.

- In the case where you are unable to angle panels (eg. Under a doorframe or radiator), you must cut away the locking edge of the lip of the bottom groove by using a wood chisel. Run a bead of glue on the now modified tongue and groove. Tighten the panels gently with the use of a pull bar and a hammer.
- If a doorframe must be undercut, lay a plank of flooring next to the doorframe with the patterned side facing down. Undercut the doorjamb with a saw, then slide the flooring plank under the doorjamb with the decorative pattern facing upwards. Please note that the floor must be allowed to expand under the doorjamb and recommended expansion gap must be respected.
- Ensure there is a minimum 3/8" (10mm) to 1/2" (12mm) gap around the entire floor perimeter and all fixed vertical objects. Measure and cut the last boards to fit so that there is a minimum 3/8" (10mm) to 1/2" (12mm) gap along the last wall.
- To prevent water spill from getting under the floor, it is recommended to install a foam backer rod in the perimeter expansion space and add a bead of silicone where the base mouldings meet the floor.
- Remove all temporary shims, sweep & vacuum immediately.
- Note: You **must** use a "T" moulding transition strip between rooms (use silicone to seal under the mouldings). Failure to do so may cause damage to the floor and will void the warranty.

NOTE: If you wish to remove a plank that has already had the end joints locked together, lift the installed plank to disengage it from the long side profile and slide the joints apart, do not force the end joints apart by lifting it upwards, it will permanently damage the end locking profile.

Finishing Details and Maintenance:

- General cleaning: It is recommended that you sweep & vacuum the area immediately after installation to remove potential damaging grit and debris. A further cleaning with an approved pre-finished laminate floor cleaner is also recommended, as required. Do not wax or use cleaning products that contain surfactants. **Never** steam clean the floor.
- Water spills should be cleaned up immediately (or within a maximum of 96 hours).
- Baseboards and quarter rounds: Replace or install new matching baseboards and quarter rounds in all areas. If baseboards and quarter rounds require finishing, it is best to pre-finish them in a separate area to avoid spilling on the laminate floor. Baseboards are to be nailed into the wall and quarter rounds into the baseboards. **DO NOT** nail either of these into the laminate flooring.
- Transition pieces: If you have removed any transition pieces and not covered their place with laminate flooring, reinstall them immediately (with a bead of silicone to seal).
- Furniture & appliances: If you are moving and placing furniture and appliances in areas with laminate floors, cover all feet and floor contact points with heavy self-adhesive felt pads to protect the floor. Lift objects when moving (furniture or appliance) DO NOT slide them.
- Felt pads on chair legs should be replaced periodically, as they wear and accumulate grit with use and can damage the floor.

- Outdoor footwear, hard soled shoes and stiletto type heels should not be worn when walking on your laminate floor, as they may dent, abrade or otherwise damage the surface and finish of your floor.
- Keep pet nails trimmed, especially dogs, as they may damage the floor.
- Toilet training accidents should be cleaned immediately. Do not keep litter boxes or food/water dishes directly on the flooring.

Water Resistant Laminate Limited Flooring Warranty:

This warranty is subject to the procedures, recommendations, limitations, disclaimers and exclusions mentioned herein and in the general information, installation and warranty sections of this document.

The water proof warranty warrants against damage from surface water spills for up to 96 hours. Damage to the floor planks caused by any water/liquid that gets under the flooring is not covered by this warranty.

Laminate flooring products carry a limited residential warranty * (SEE NOTE AT BOTTOM OF WARRANTY) applicable to the first owner and first installation in a private residence, against manufacturer and workmanship defects when used under normal conditions and installed in accordance with the manufacturer's installation instructions. The "first owner" is the person stated as the buyer on the flooring purchase documents and is not transferable. Consult your original packaging for the warranty time specific to the product you have purchased. Note that you must retain an original label of the product purchased which denotes your warranty duration, as well as the UPC code and your original receipt of purchase. This warranty is not transferable. Manufacturer's warranty and liability does not extend beyond the flooring strips and is limited to a maximum value of the original purchase price. Warranty is limited to repair or replacement of the strips at the sole option of the manufacturer. The warranty does not include labour and installation costs nor any secondary costs. Claim compensation (if approved and/or authorised by Power Dekor NA) is limited to the specific area which Power Dekor NA deems to be valid under the claim.

This warranty does not cover and specifically excludes such damages as: indentations, scratches, dents, chips, pet damages and stains caused by normal wear and tear, sheen loss in high traffic areas, erosion from pebbles, stones, sand, all other abrasives, steam cleaning, inadequate protection, insects, rot, mould, mildew, bacteria, lack of maintenance, weather conditions, fire, water, high humidity, excessive dryness, natural disasters, excessive heat, heating and air conditioning systems, accident, improper installation or handling, cleaning agents, negligence or other causes not attributed to manufacturing or workmanship defects. Failure to adhere to and follow all the manufacturer's instructions for installation and maintenance and incorrect or insufficient maintenance. Any modification to the product other than as outlined in the manufacturer's installation instructions will render the warranty null and void.

The warranty excludes claims due to the development of naturally occurring flaws, stresses, warping, cracks, split ends or other flaws within the product which manifest over time, whether or not caused by age, low or high humidity, seasonal humidity changes, improper maintenance, uncontrolled environmental conditions or other natural causes.

This warranty does not cover natural contraction (loose boards and cracks/gaps between boards) or expansion (cupping of boards, buckling and warping), whether or not caused by excessively low or excessively high humidity. Nor does this warranty cover secondary damages caused by floor expansion/contraction or installation environment where the boards were installed.

This warranty excludes noises of all types (creaks, squeaks etc.) emanating from the floor and/or subfloor.

This warranty excludes floors which have been installed in areas without adequate humidity control and/or when humidity has not been continuously maintained within required humidity level throughout the entire year as required herein.

This warranty excludes differences in or changes to gloss levels in an installed floor. Installation is considered acceptance, regardless to changes to lighting conditions after installation.

This warranty excludes claims due to differences in the colour and texture from display models and literature, as well as differences in colour and texture from board to board.

This warranty excludes bows in boards: it is the nature of boards to bow seasonally due to changes in relative humidity.

The warranty excludes claims due to natural lightening or darkening of the product from exposure to light, or to areas which have not darkened due to less exposure to light than surrounding areas.

This warranty explicitly excludes products sold "as is". The original purchaser is responsible for correct installation, maintenance and cleaning of the flooring in accordance with the included instructions.

This warranty specifically excludes damages to floors caused by heating systems: heating ducts, heat sources and heating system components of all types.

This warranty specifically excludes colour variances from one dye/batch number to another. Prior to installation, verify the colours are an acceptable match. Co-install all batched in evenly distributed and well mixed manner.

In the case of claims for commercial installations, please note the following should your floor carry a limited commercial warranty. If applicable, the limited commercial warranty is only applicable to "light commercial" use and applications, which are defined as follows: low traffic areas in commercial offices, showrooms and retail spaces. In all cases, installed areas must not be subject to wet or abrasive debris or other conditions caused by wet or dirty footwear, these types of conditions will void the warranty. High traffic areas as defined previously herein are excluded from this warranty.

Power Dekor NA warrants to the original user that its products, when in their original manufactured condition, aside from previously mentioned information and exceptions, will be free from defects and dimensional inconsistency during the warranty period when installed and used under normal residential use in accordance with the terms, installation instructions, limitations and conditions herein. Power Dekor NA warrants to the original user that the finish on its products will not wear through nor separate from the flooring during the warranty period when installed and used under normal residential use in accordance with the terms, installation instructions, limitations and conditions herein.

This warranty is the entire and sole statement of warranty for the product and replaces any and all previous warranties, written, spoken, implied or otherwise. No implied warranties exist beyond the terms and conditions of this warranty, Power Dekor NA assumes no legal liability for any and all actual incidental and/or consequential damages, however, some states within the USA do not permit the exclusion or limitation of incidental and/or consequential damages, as such, this exclusion may not apply to you. This like all warranties gives you specific legal rights, in addition, you may also have other rights that vary from state to state or from province to province.

To file a warranty claim, contact the original supplier where the flooring was purchased.

*** NOTE:** Rental units, leased properties and apartments are considered commercial properties under this warranty. The limited residential warranty does not apply to these types of properties and installations. If your product purchase also carries a limited commercial warranty, it is the limited

commercial warranty that applies to rental units, leased properties and apartments per the condition, exclusions and terms specified herein.

Note that Power Dekor NA reserves the right to visit or have its agent visit the premise where the product claim originates to inspect the product in dispute and to remove samples for verification and technical analysis. Failure to provide reasonable access to the installation area or to provide requested information and/or documentation may result in denial of the claim.

All warranty claims must be made in writing to Power Dekor NA through the original supplier and must include a complete copy of the original purchase receipt, installation documentation, as available, and other information that may be requested by Power Dekor NA including this warranty.

For information regarding our products, please visit our web-site: www.powerdekorna.com

For questions e-mail us at: customerservice@powerdekorna.com or call toll free at: 1-844-MY-DEKOR